Initial Calibrations - Deere 8820 Combines

Monitor Serial No:

Flow Sensor Serial No:

Header Sensor: Standard

Box Cal: Voltage Cal:

Sensor Cal:

After SN#464351 – Wide Elevator — Late 8820 Scale Factor: 1.5

Before SN#464352 - Narrow Elevator — Early 8820 Scale Factor: 1.8

T1: 10 T2: 5 T3: 8

Sprocket Teeth: 8 Elevator Pulses/Rev: 1

Note: Be sure to set the above values before harvesting!

	Before S.N. 464351 (6" elev./3" impact plate)			After S.N. 464350 (8" elev./4" impact plate)		
Crop	Soybeans Edible Beans	All Corn Types	All Other Grains	Soybeans Edible Beans	All Corn Types	All Other Grains
C1	100	100	100	100	100	100
C2	200	400	200	250	500	250
C3	400	800	400	500	1000	500
C4	600	1280	600	800	1600	800
C5	800	1600	800	1000	2000	1000
C6	1000	2000	1000	1250	2500	1250
C7	1200	2400	1200	1500	3000	1500
C8	1400	2800	1400	1750	3500	1750
C9	1600	3200	1600	2000	4000	2000
C10	1800	3600	1800	2250	4500	2250
C11	2000	4000	2000	2500	5000	2500
S1	75	50	75	75	50	75
M1	400	650	705	400	650	705
% OFFSET	+4.7	+3.5	+2.0	+4.7	+3.5	+2.0

Ag Leader Technology

Rev N/C 2/25/1998